

Installation Instructions (original)

Transportation I Assembly I Operation I Maintenance



Productline:	Blastfreezers
Series description:	Shock frosters R134a,R404A,
Series:	GFN

www.bitzer.com.au

Contents

1	<u>Impor</u>	Important basic information.	
	1.1	Safety instructions	5
	1.1.1	Observing operating instructions.	5
	1.2	Importance of the EN 378 series of standards – refrigeration	
		systems and heat pumps – safety-related and environmental	re-
		<u>quirements</u>	5
	1.3	Responsibilities	5
	1.3.1	Manufacturer's responsibilities.	5
	1.3.2	Responsibilities of the system's installer.	6
	1.3.3	Owner or operator responsibilities.	6
	1.4	<u>Legal notes</u>	7
	1.5	Operating instructions	7
	1.5.1	Scope	7
	1.5.2	Set-up and other applicable documents.	7
	1.6	Conventions	8
	1.6.1	Typographical conventions	8
	1.6.2	List of abbreviations.	8
	1.7	Conventions for safety signs and noticesGeneral safety	9
	1.7.1	signs and their meaning in these operating instructions	
		Warning symbols and their meaning in these operating instruc-	9
	1.7.2	tions	
		Prohibitory signs and their meaning in these operating instruc-	9
	1.7.3		
		tions	10
	1.7.4	Mandatory signs and their meaning in these operating instruc-	
		tions.	10
2	Safety	/	12
	2.1	Labelling on the unit:	12
	2.1.1	Safety signs on the unit.	13
	2.1.2	Other signs and notes on the unit.	15
	2.2	Basic safety notices.	17
	2.2.1	How to act in an emergency.	17
	2.2.2	Personnel, care requirements.	18
	2.3	Proper intended use.	18
	2.3.1	Proper intended use.	18
	2.3.2	Operating conditions	19
	2.3.3	Improper use	19
	2.4	Mechanical residual hazards.	21
	2.4.1	Fins, sharp unit corners and edges.	21
	2.4.2	<u>Fans</u>	21
	2.5	Electrical residual hazards.	22



	2.6	Thermal residual hazards.	22	
	2.6.1	Frostbite hazard	22	
	2.7	Residual hazards due to CFC/HFC refrigerants	22	
	2.8	Residual hazards caused by vibrations.	24	
	2.9	Residual hazards caused by pressurised parts.	24	
	2.10	Residual hazards caused by defective installation.	25	
	2.11	Residual hazards with break during operation.	26	
	2.12	Residual hazards caused by escaping objects or liquids	26	
	2.13	Residual hazards with disposal.	27	
3	<u>Tech</u>	Technical data		
	3.1	<u>Unit</u>	28	
	3.2	<u>Fans</u>	28	
4	Set-u	p and function	29	
5	Fan r	<u>motor</u>	30	
6	Trans	sportation and storage	31	
	6.1	<u>Safety</u>	31	
	6.2	Transportation and storage.	31	
	6.3	Storage before installation.	32	
7	Set-u	ıp and start-up.	33	
	7.1	<u>Safety</u>	33	
	7.1.1	Safety instructions for set-up and start-up	33	
	7.1.2	System-side safety requirements.	34	
	7.1.3	Customer-side safety precautions.	35	
	7.2	Requirements at the set-up point	36	
	7.3	Unpacking the unit.	37	
	7.4	<u>Installation</u>	38	
	7.4.1	System-side requirements for stress-free installation	38	
	7.4.2	Mounting the unit.	40	
	7.5	Notes on connecting the unit. Connecting	41	
	7.5.1	the thermostatic expansion valve Connecting	41	
	7.5.2	the drain line to the drip tray.	42	
	7.5.3	Connect the unit to the system.	42	
	7.5.4	Unit electrical connection and protection	43	
	7.6	Perform acceptance test.	44	
	7.7	Test readiness for operation.	45	
	7.8	Putting the unit into operation for the first time	45	
8	<u>Oper</u>	<u>ation</u>	47	
	8.1	<u>Safety</u>	47	
	8.2	Putting the unit into operation	47	
	8.3	Taking the unit out of operation.	47	



	8.4	Shutting the unit down.	48
	8.5	Putting the unit into operation after a shutdown.	49
	8.6	Changing the unit over to another working fluid.	49
9	Trouk	oleshooting	50
	9.1	<u>Safety</u>	50
	9.2	Service.	50
	9.3	<u>Troubleshooting table</u>	50
10	Maint	tenance	51
	10.1	Safety	51
	10.1.1	Before starting all maintenance.	51
	10.1.2	With all maintenance work.	51
	10.1.3	After all maintenance work.	52
	10.2	Inspection and maintenance plan.	53
	10.2.1	<u>Fans</u>	53
	10.2.2	Unit heat exchanger.	53
	10.3	Maintenance work	55
	10.3.1	Remove leaks.	55
	10.4	Clean unit.	55
	10.4.1	General	55
	10.4.2	Clean and defrost heat exchanger	55
	10.4.3	<u>Cleaning fans</u>	57
	10.5	Defrosting the unit.	58
	10.5.1	Notes on defrosting.	58
	10.5.2	<u>Defrost control</u>	59
	10.5.3	Circulation air defrosting.	60
	10.5.4	Electric defrosting	60
	10.5.5	Hot gas defrosting (option).	60
	10.5.6	Further notes on defrosting.	60
11	Plans	s/diagrams	61
	11.1	Electrics documentation	61
	11.1.1	Fan motor connection diagram.	61
	11.1.2	Connection diagram electrical defrost.	61



1 Important basic information

1.1 Safety instructions

1.1.1 Observing operating instructions

⚠ CAUTION

- Always keep the operating instructions in the unit's immediate vicinity at all times.
- Ensure that the operating instructions are accessible to all people that have anything at all to do with the unit at alltimes.
- Ensure that the operating instructions are read and understood by all people that have anything at all to dowith the unit.

1.2 Importance of the EN 378 series of standards – refrigeration systems and heat pumps – safety-related and environmental requirements

EN 378 deals with safety-related and environmental requirements for designing, constructing, producing, installing, operating, maintaining and disposing of refrigeration systems and cooling equipment.

EN 378 is oriented towards manufacturers, installers and operators of refrigeration systems and cooling equipment (see section 1.2. Responsibilities).

The objective of EN 378 is to restrict the possible hazards of refrigeration systems, cooling equipment and their working fluids (refrigerants and coolants) for people, property and the environment to a minimum.

Insufficient safety measures or non-compliance with safety-relevant regulations can result in:

- Breaks or ruptures on components with the danger of escaping materials (hazards caused by the influence of low temperatures, excess pressure, direct influence of the fluid phase, moving machineparts).
- Escaping working fluid after a break or leak because of defective design, improper operation, insufficient maintenance, repairs, filling and disposal (hazards caused by oxygen deficiency, flammability, frostbite, suffocation, panic)
- · Fire or explosions of escaping working fluid with subsequent danger of fire.

1.3 Responsibilities

1.3.1 Manufacturer's responsibilities

The notes provided in these operating instructions on maintaining the unit's functional safety, preventing possible hazards when transporting, setting up and installing, start-up and operation, and with maintenance activities (cleaning, servicing and repairing) refer exclusively to the unit.

The manufacturer's responsibilities are documented in the unit's version in acc. with EN 378-2 (design, manufacture and testing).



The materials used in the construction and for soldering and welding are designed to withstand the foreseeable mechanical, thermal and chemical stresses, and are resistant to the working fluids used and to mixtures of such working fluids and the oils used to lubricate refrigeration compressors.

The working fluid-carrying parts of the unit (core tubes, distributor tube and header outlet) are configured so that they remain tight with the foreseeable mechanical, thermal and chemical stresses, and withstand the maximum permissible operating pressure.

Material, wall thickness, tensile strength, corrosive resistance, shaping process and testing are suitable for the working fluid used and withstand the possible pressures and stresses that might occur.

All responsibility for the equipment into which the unit is integrated, are the exclusive responsibility of the people involved in the individual workflows.

1.3.2 Responsibilities of the system's installer

The responsibilities of the system installer are documented in the system's version (design, manufacture and testing – in accordance with EN378-2.

Component supplier-system installer interfaces:

In the event of any malfunction, inform Güntner GmbH & Co. KG:
 Inform Güntner GmbH & Co. KG immediately if faults occur during the set-up, installation, start-up and operation..

The responsibilities of the system installer in particular include:

- Planning and preparing emergency measures:
 To avoid consequential damage caused by operational disruptions, a warning system which immediately signals all faults must be provided on-site. Prepare emergency measures that prevent consequential damage for people and property should faults occur.
- Specify checking and maintenance intervals:
 The system must be configured and equipped with all required equipment for maintenance and sufficient servicing and testing in accordance with EN 378-4.

When the unit is integrated into the refrigeration system, the working fluid and version must not deviate from the order-related information specified in the order-related documents.

The installer of the system must refer to the requirement for sufficient instruction of the operating and supervision staff when operating and maintaining the equipment.

It is recommended that the future customer staff – if possible – be present during the set-up and installation, for tightness tests and cleaning, while the system is being filled with working fluid and for the adjustment of the equipment .

1.3.3 Owner or operatorresponsibilities

The owner or operator responsibilities are documented in the operation, maintenance, servicing and recovery of the system in accordance with EN 378-4.

The owner or operator must ensure that the proper people are sufficiently trained and qualified for operating, monitoring and servicing the system.

The operating personnel for the system must have sufficient knowledge and experience with regard to the mode of operation, operation and daily monitoring of this system.

Before starting up the system, the owner or operator must ensure that the operating personnel are sufficiently instructed about the system's documentation (which is part of the operating instructions) on the set-up, monitoring, mode of operation and servicing of the system and the safety measures to be observed, and with regard to the properties and handling of the working fluid to be used.



The owner or operator must ensure that when operating, monitoring and maintaining the system the working fluid and version must not deviate from the details specified in the order-related documents.

Planning and preparing emergency measures: To avoid consequential damage caused by operational disruptions, a warning system must be installed on the customer's premises. Prepare emergency measures that prevent consequential damage for people and property shouldfaults occur.

Responsibility remains with the owner or operator of the system, if the system are used by anybody else, unless there is a contrary agreement on sharing responsibility.

1.4 Legal notes

Warranty claim expires as follows:

- With faults and damages that can be attributed to non-compliance with the specifications of these operating instructions.
- With complaints that can be attributed to use of spare parts other than the original spare parts specified in the order-related offer documents.
- With changes to the unit (working fluid, version, function, operating parameters) vis-a-vis the order-related information specified in the order-related offer documents without the manufacturer's prior consent.

The operating instructions may not be reproduced electronically or mechanically, circulated, changed passed on to third parties, translated or used otherwise, in full or in part, without Güntner GmbH & Co. KG's prior explicit written approval.

1.5 Operating instructions

1.5.1 Scope

These operating instructions series for all blast freezers of the GFN series.

NOTICE

You will find the precise type of your unit in the attached order-related documents.

1.5.2 Set-up and other applicable documents

The unit's operating instructions include the following parts:

- These instructions
- Order-related documents

The order-related documents are included with these instructions and contain the following information:

- The order-related proper use as specified
- The order-related scope of delivery
- The order-related technical data
- The order-related drawings specifying customer, project number and order number
- · Motor connection wiring diagram in terminal boxes

These operating instructions are part of the operating instructions manual of the system, provided by the system's installer.



1.6 Conventions

1.6.1 Typographical conventions

The following text markups are used in these operating instructions:

Bold	Requires special attention!
Greytriangle	Instructions

1.6.2 List of abbreviations

Abbreviations	Meaning
CFC/HFC	Alkane group refrigerant, e.g. R134a, R404A, R407C,
EN378	European Norm 378: Refrigeration systems and heat pumps; safety-related and environmental requirements
EN	EuropeanNorm
DIN	German industrial standard (specification of a standard)
ISO	International Standardization Organization.
°C	Degrees Celsius (Celsius scale temperature)
is	Unit of pressure
I	Litre (liquidvolume)
Vol%	Volume percent (concentration level relative to a volume)
IP	Insulation protection
Q6,3	Balancing quality
ppm	parts per million, concentration figure, stands for "millionth part".
Hz	Hertz(frequency)
D	Delta connection (alternating current: high speed)
S	Star connection (alternating current: low speed)
3~	3-phasecurrent
1~	1-phase alternating current
VDE	"Verband der Elektrotechnik, Elektronik und Informationstechnik" (Association for Electrical, Electronic & Information Technologies)
TCC	Technical Connection Conditions
EPC	Electric Power Company
VDI	"Verein Deutscher Ingenieure" (German engineers' association)



1.7 Conventions for safety signs and notices

1.7.1 General safety signs and their meaning in these operating instructions

DANGER

Dangerous situation that will definitely cause serious injury or death if it is not avoided.

⚠ WARNING

Dangerous situation that could cause serious injury or death if it is not avoided.

⚠ CAUTION

Dangerous situation that could cause slight to moderate injury if it is not avoided.

NOTICE

Refers you to possible damage toproperty.

1.7.2 Warning symbols and their meaning in these operating instructions



Warns against hand injuries!

Failure to comply with warnings may result in hands or fingers being crushed, dragged in or otherwise injured.



Warns against hot surfaces!

The temperature is over +45°C (at which protein clots) and can cause burns.



Warns againstcold!

The temperature is below 0°C and can cause frostbite.



Warns against dangerous electrical voltage!

Danger of an electric shock if voltage-carrying parts are touched.



Warns against fire-risk substances at set-up point.

Use of ignition sources can cause fire at set-up point.





Warns against harmful to health or irritant substances at set-up point

Contact with or inhaling substances that are irritant or harmful to health can cause injuries or damage peoples' health.



Warning of automatic start-up

If the unit starts up automatically during maintenance work there is a danger of pinching/trapping the hands and fingers.



Warns against toxic substances at set-uppoint

Contact with or inhaling toxic substances can cause injuries or damage the health.

1.7.3 Prohibitory signs and their meaning in these operating instructions



Fire, open fire and smokingprohibited!

Ignition sources must be kept away and ignition sources must not develop!



Nosmoking!

Smoking is forbidden.

1.7.4 Mandatory signs and their meaning in these operating instructions.



Use eye protection!

Eye protection: Use protective cover, protective glasses or face protection.



Use handprotection!

Protective gloves must protect against mechanical and chemical dangers (see imprinted pictograms).



Use respiratory protection!

Breathing apparatus must be suitable for the working fluid used. Breathing apparatus must consistof:

At least two independent breathing devices (self-contained breathing apparatus)





Use protective clothing!

Personal protective clothing must be suitable for the working fluid used and for low temperatures, and must have good heat insulation properties.



Activate before work!


Activate the electrical system and secure against switching on again before starting installation, maintenance and repair work.



2 Safety

2.1 Labelling on the unit:

Placing identifiers on the unit




Placing identifiers on the unit




2.1.1 Safety signs on the unit

Safety signs on the unit individually:



940 - "Transportation filling" warning sign next to Schradervalve



4413 - "Do not use wrench" warning sign besidetray drain



Servicedeckel • Inspection door • Panneau de service



Achtung: Vor dem Öffnen dieses Deckels Gerät immer spannungsfrei schalten.

Caution: Before opening this door the power supply

Of the unit should be switched off. Attention: Mettez l'appareil hors tension avant

d'ouvrir le panneau de service.

938 - Warning on inspection door (only with hinged fans)

Achtung • Caution • Attention

Ventilator-Betrieb nur mit Schutzgitter! **Gefahr!**

Fan operation only with guard grille!

DANGER!

Mode operatoire de ventilateur qu'avec brille protectvice!


DANGER!

Art.Code:3083

3083 - "Protection grill" warning sign (only used with separate removable protection grill)



2.1.2 Other signs and notes on the unit



2483 - Example of a manufacturer's nameplate




2119 - Logo



943 and 943.1 - Connections IN and OUT





13 - Expansion valve mounting




ACHTUNG - ATTENTION - ATTENTION - ATENCIÓN

Bei der Verwendung von Reinigungsmitteln in Kühlräumen, ist auf die Korrosionsbeständigkeit der Materialien des Kühlers gegenüber dem verwendeten Reinigungsmittel zu achten! When cleaning agents are used inside the cold room, the corrosion resistance of the cooler materials to the applied cleaning agent has to be observed!

Lors de l'utilisation des détergents dans les chambres froides, il faut observer la résistance à la corrosion des matériaux de l'appareil qui entrent en contact direct avec les détergents. Cuando se apliquen agentes limpiadores en los productos instalados en cámaras frías, se debe tener cuidado que no corroen los materiales usados para la construcción del producto!

947 - Corrosion resistance



15 - Forklift use (visible onpackaging)

2.2 Basic safetynotices

2.2.1 How to act in an emergency

WARNING

Danger of injuries!

the CFC/HFC refrigerants that are used (R134a, R404A, R407C, ...) are Group L1/A1 refrigerants compliant with classification according to flammability (L) and toxicity (A) in compliance with EU Directive 97/23/EC for pressure equipment (Pressure Equipment Directive):

- Refrigerants that, when gaseous, are non-flammable irrelevant of their concentration in air.
- Refrigerants with a time-weighted, averaged concentration that have no adverse effects on the majority of staff that are exposed every day during a normal 8 hour working day and a 40 hour working week to this concentration, which is greater than or equal to 400 ml/m ³(400 ppm (V/V)).

There is no imminent danger for the staff. However, refrigerants of the Group L1/A1 are generally heavier than air and may flow off to rooms on a lower level. In still air there may be an increase of the



ground level concentration. With high concentrations there is a danger of suffering from disordered cardiac rhythm and suffocation due to a reduced oxygen concentration, especially at ground level. Unauthorised people must not have access to the unit. Please ensure that the CFC/HFC refrigerant escaping from the unit cannot penetrate the interior of the building or put people at risk in any other way.

Safety measures and procedure:

- In the event of serious unexpected leakage of refrigerant, leave the set-up room immediately and activate the emergency measures provided, e.g. if:
 - Visibly escaping refrigerant liquid or vapour from the heat exchanger or pipe components.
 - there is a sizeable sudden escape (escape and evaporation of the greater part of the entire refrigerant filling within a short time, e.g. in less than 5 minutes);
 - Activation of the refrigerant detector (limit value in accordance with EN 378-1; Annex E):
- Have experienced, trained personnel with prescribed protective clothing perform all necessary protective and othermeasures:
 - Use respiratory protection.
 - Use a room air-independent breathing apparatus with maintenance work in high refrigerant concentrations in the roomair.
 - Ensure the set-up room is well ventilated.
 - Divert escaped refrigerant vapour and escaped refrigerant liquid safely.
 - Ensure that no refrigerant enters watersystems orsewage.

2.2.2 Personnel, care requirements

↑ CAUTION

The unit may be installed, put into operation, operated, maintained and repaired only by trained, experienced and qualified personnel. In order to be considered qualified, people who are to be responsible for the operation, maintenance, repair and evaluation of systems and their components must have the necessary training and specialist knowledge for such work, as stipulated in EN 378-1. Qualified or expert means the ability to satisfactorily perform the activities required for the operation, maintenance, repair and evaluation of refrigeration systems and their components.

The unit may be operated by operating personnel that have no specific knowledge of refrigeration engineering, but have sufficient knowledge and experience with regard to the mode of operation, operation and daily monitoring of this system, . This operating personnel may not make any interventions or settings on the system.

Changes to the unit, which the manufacturer has first agreed to in writing, may only be made by the instructed and qualifiedpersonnel.

Electrical installation:

Work on the electrical equipment may only be performed by personnel that have the required expertise (e.g. an electrician or an electro-technically instructed person), and who are authorised by the operator, in compliance with the respective VDE regulations (and national and international provisions) and the TCCs of the EPCs.

2.3 Proper intendeduse

2.3.1 Proper intendeduse

Shock frosters in the GFN series are intended for installation in a refrigeration system and are used for cooling and circulating the room air HFC – for example, for blast freezing tightly packed goods, or in freezing tunnels.



The unit is delivered for operation with a specific operating point:

- Evaporation temperature
- Airflowvolume
- · Air inlettemperature

The specified operating point is given in the order-related documents.

2.3.2 Operating conditions

The unit is a component a cooling system including its working fluid circuit. The purpose of these operating instructions, as part of the operating instructions manual (of which these operating instructions are a part), is to minimise the danger to people and property and the environment from the unit and the working fluid used in it. These dangers are essentially connected with the physical and chemical properties of the working fluid and with the pressures and temperatures that occur in the working fluid-carrying components of the unit see Residual hazards due to CFC/HFC refrigerants, page 22.

MARNING

Danger of injuries and damage to property!

The unit may be used only in accordance with the proper intended use. The operator must ensure that when operating, monitoring and maintaining the unit, the fluid used and the mode of operation do not deviate from the order-related information specified in the order-specific documents.

The operator must ensure that maintenance measures are performed in compliance with the system's operating instructions manual.

Filling the unit with a different fluid is permitted only following written approval by the manufacturer. You will find the order-related proper use as intended in the order-specific documents.

Do not exceed the max. operating pressure given on the unit's type plate.

2.3.3 Improperuse

↑ **WARNING**

Danger of injuries and damage to property!

Working fluids and their combinations with water or other substances in the working fluid-carrying components have chemical and physical effects from the inside on the materials surrounding them. The unit may be pressurised only with CFC/HFC refrigerant . Pressurising the unit with another working fluid would have the effectthat

- the structural, soldering and welding materials used do not withstand the foreseeable mechanical, thermal and chemical stresses, and the pressure that can occur during operation and when shut down is notwithstood.
- material, wall thickness, tensile strength, corrosive resistance, shaping process and testing are not suitable for the working fluid used and do not withstand the possible pressures and stresses that mightoccur.
- the unit would not be resistant to the other working fluid and the combination of the other working fluid and
- the unit not remaining tight during operation and when shut down.
- a possible sudden escape of working fluids could directly endanger people and/or property and the environment.



The maximum permissible operating temperature specified on the type plate must not be exceeded! If the operating temperature is exceeded,

- the unit would be exposed to an impermissibly high pressure (pressure/temperature correlation),
- · signs of material fatigue wouldemerge,

The maximum permissible operating pressure specified on the type plate must not be exceeded! If the operating pressure is exceeded,

- the parts of the unit carrying the working fluid might not withstand the foreseeable mechanical, thermal and chemical stresses and the pressures that may occur during operation and when shut down,
- the unit would not remain tight during operation and when shut down,
- there may be a possible sudden escaping of working fluids after a break or leakage on working fluid-carrying components, which would result in the followingdangers:
 - Danger of escapingmaterials
 - Danger of poisoning
 - Dangers caused by oxygendisplacement
 - Fire hazard (caused by refrigerator oil parts)
 - danger of frostbite (caused by liquid coolant squirting/splashing),
 - Suffocationhazard
 - hazards caused by panicreactions,
 - Environmental pollution

⚠ WARNING

CFC/HFC Shock frosters may not be used

- where it is possible that short or prolonged effect caused by contact, inhalation or ingestion of the working fluid might result in harmfulhazards.
- where the possibility exists of a sudden large release (release and evaporation) of the greater part of the entire working fluid filling in a short time (e.g. in less than 5 minutes).

The unit must not be changed without the prior written consent of Güntner GmbH & Co. KG . Changes to the unitare:

- Changing the operating point (as specified in section <u>see Unit, page 28)</u>
- Changing the fan capacity (airvolume)
- Changing the working fluid flow-throughvolume
- Changing over to another working fluid

The unit must not be operated if safety devices recommended by the manufacturer are not available, not properly installed or not fully functional.

The unit must not be operated if it is damaged or demonstrates faults. All damage and faults must be reported to Güntner GmbH & Co. KG immediately and dealt with promptly.

Work on the unit must not be performed without the personal protective equipment specified in these operating instructions.



2.4 Mechanical residualhazards

2.4.1 Fins, sharp unit corners and edges

⚠ WARNING



Warns against handinjuries!

Danger of cuts on hands and fingers on the fins and on sharp corners and edges of theunit.



Use reliable handprotection!

2.4.2 Fans

MARNING



Danger of cutting off, pullingin!

There is a danger of cutting off fingers on the rotating fan blades, injury hazard for the hands and pulling in danger for loose elements such as hair, necklaces or clothing parts.



Do not operate fans without guard grille. Pinch/trap point hazard!

With automatic fan start during maintenance work there is a danger of pinching/trapping for the hands and fingers.



Power off the unit before you begin maintenance work with which you must remove the guard grille. Secure the unit against unintentional switching on again by removing the electric fuses for the unit. Secure the unit with a suitable warning sign referring to unintentional switchingon.



2.5 Electrical residualhazards

MARNING



Warns against dangerous electrical voltage!

Direct and indirect contact with voltage-carrying parts of motors and electrical lines can cause serious injuries ordeath.



Power off the unit before you begin maintenance work. See the refrigeration system's system documentation for this. Secure the unitagainst unintentional switchingon again by removing the electric fuses for the unit. Secure the unit with a suitable warning sign referring to unintentional switchingon.

Please note that the mains cables may also be carrying voltage, even if the unit is powered off.

Work on electrical equipment may be performed only by people that have the required expertise (e.g. an electrician or an electro-technically instructed person) and who are authorised to do so by the operator.

2.6 Thermal residualhazards

2.6.1 Frostbitehazard

MARNING



Warns against cold!

In refrigeration operation the heat exchanger and pipes have a temperature below ± 0 °C. Contact can cause frost bite.

Use handprotection!



2.7 Residual hazards due to CFC/HFCrefrigerants

The CFC/HFC refrigerants that are used (R134a, R404A, R407C, R507 ...) are Group L1/A1 refrigerants in compliance with classification according to flammability (L) and toxicity (A) in compliance with EU Directive 97/23/EG for pressure equipment (Pressure Equipment Directive):

- Refrigerants that, when gaseous, are non-flammable irrelevant of their concentration in air.
- Refrigerants with a time-weighted, averaged concentration that have no adverse effects on the
 majority of staff that are exposed every day during a normal 8 hour working day and a 40 hour
 working week to this concentration, which is greater than or equal to 400 ml/m³ (400 ppm (V/V)).

There is no imminent danger for the staff. With good air ventilation and removal by suction, it will fall easily and clearly below the allowed limit values.



M WARNING

Danger of harm to health and environmental damage!

Refrigerants of the Group L1/A1 are generally heavier than air and may flow off to rooms on a lower level. In still air there may be an increase of the ground level concentration. With high concentrations there is a danger of suffering from disordered cardiac rhythm and suffocation due to a reduced oxygen concentration, especially at groundlevel.

- Unauthorised people must not have access to the unit.
- Ensure working rooms are well-ventilated in order to prevent inhalation of high vapour concentrations.
- Please ensure that the CFC/HFC refrigerant escaping from the unit cannot penetrate the interior of the building or put people at risk in any other way. CFC/HFC refrigerant vapourgoasrmust be kept from penetrating neighbouring rooms, staircases, yards, passages or drainage systems andmust be discharged withoutrisk
- Monitor the CFC/HFC refrigerant concentration in the ambient air to ensure constant compliance with limit/values.
- Test the tightness of the unit regularly, as specified in these operating instructions eesl(nspection and maintenance plan, page 53).



Ignition and firehazard!

- With work involving fire or sparks, e.g. grinding, welding, etc., ensure suitable fire fighting equipment is on-site.
- In particular be aware of the danger of ignition of unintentionally carried in oil residues or CFC/HFC refrigerant.



- Ensure that the provided fire fighting equipment is provided in sufficient quantities, that it functions properly and that the extinguishing agent does not react with the CFC/HFC refrigerant.
- Smoke during work isforbidden!



Frostbitehazard

Splashes of CFC/HFC refrigerant that is superheated can cause frostbite to the eyes and skin.

 When removing faults after spills of CFC/HFC refrigerant, you must be vigilant for any remaining superheated CFC/HFC refrigerant.



Danger of poisoning!

CFC/HFC refrigerant contact with fire can form toxic combustion products.

- Prevent CFC/HFC refrigerant contact with openfire.
- Welding and soldering may therefore take place only after completely draining the relevant section of the system of the CFC/HFC refrigerant. Ensure good ventilation here!



With emergency work in high refrigerant concentrations in the room air wear a room air-independent breathing apparatus.



2.8 Residual hazards caused by vibrations

⚠ WARNING

Danger of injuries and damage to property caused by escaping materials

If fans are damaged during fan operation, flying parts of the fan blades can injure people or cause damage to property close to the fan.

Fans, components and cables in system, must be designed, constructed and integrated so that dangers caused by vibrations that it or other parts of the system generate,, are reduced to an absolute minimum, while incorporating all available means for reducing vibrations, preferably at the source.

NOTICE

Damage to property caused by vibrations

Vibrations that are increased by imbalances, as created by dirt, frosting, icing or fan blade damage, are regularly caused with fan operation. The vibrations are transferred to the unit, where they can cause damage and damage the unit mounting or components connected to the unit.

Check fan blades and protection grill regularly for contamination and frost and/or ice and make sure the fans run smoothly (see Fans, page 53).

2.9 Residual hazards caused by pressurised parts

MARNING

Injury and damage to property caused by pressurised parts that contain CFC/HFC refrigerant!

Breaks in pressurised pipes or pressurised components of the unit can cause injuries or damage to property caused by escaping materials (A sudden large release of the working fluid with its hazardous properties after a break or leak on pressurised components of the unit can cause the following hazards:

- Toxicity
- Oxygen displacement
- Flammability caused by proportion of lubricating oil for refrigerating compressors present
- Frostbite (caused by liquid refrigerant squirting/splashing)
- Suffocation
- Panic,
- Environmental pollution

Ensure that the unit in question is pressure-free before maintenance work begins or remove the working fluid from the unit in question.

Perform maintenance work – especially soldering and welding – on the unit in question only after completely removing the working fluid from the unit.



2.10 Residual hazards caused by defective installation

M WARNING

Injuries and damage to property caused by defective installation!

Defective installation results in hazards causedby:

- Break or leak on liquid-carrying unit components and pipes
- Taking the refrigerant pumps out of service: When switching over a duty pump to a reserve pump: If the duty pump is shut off at both ends from the previous operating state, liquid, cold refrigerant remains in the pump. In shutdown state the refrigerant heats up in the pump and causes leaks with housing or flangecracks.
- Uneven load distribution on the fixtures with the danger of stresses within the unit or unit displacement (breaks or leaks on fluid-carrying components of the unit and pipes; danger of breaking off).
- Insufficient securing of working fluid-carrying lines against mechanical damage! On-site connections: loaded installation; effect of forces on the distribution and header pipes with the danger of breaks or leaks on fluid-carrying components of the unit and pipes; danger of breaking off!
- Break-off danger of the unit with hazard of escaping working fluid and exposed electrical cables.
- Danger of damage caused by environment-conditional hazard sources (production, transport and other processes at the set-uppoint).
- Unit functional faults caused by air inlet/outletobstructions.
- Obstruction of all-side inspection, checks and maintenance, i.e. no unobstructed accessibility to the
 working fluid-carrying and electrical components, connections and cables, no recognisable identifiers
 on the pipes and insufficient space for tests.

Ensurethat:

- The units are to be installed on the fixing points corresponding with their weights and tightened with fixing bolts. The operator or installer is responsible for ensuring that the bolted connections are of an adequate strength.
- The diameters of the mounting holes have been statically determined by the manufacturer and the fixing bolts are adapted accordingly.
- The fixing bolts are secured against loosening by means of an appropriate locking device.
- The fixing bolts are not overtightened or stripped.
- All fixing bolts are tightened equally to achieve a load distribution on the connections that is as balanced aspossible.
- All fixing points maintain the same spacing to the fixing level permanently and under load, so that no
 mechanical stress occurs in the unit structure. The units are anchored in their fixing position in order
 to prevent the equipment frommoving.
- The functional safety of the fixing bolts is tested as part of the maintenance periods, see Maintenance, page 51,
- The unit is fixed and set up so that it is not damaged by environment-conditional hazard sources (production, transport and other processes at the set-up point) or its functioning is not disturbed by the interventions of unauthorisedpersons.
- The units are fixed and set up with sufficient slopes for dripwater flow.
- The units are fixed and set up so that unobstructed air inlet/outlet is constantly available without any air shortcircuiting.
- The units are fixed and set up so that unobstructed heater rod exchange with electric defrosting is constantly available (option: accessory at customer's request).
- The units are fixed so that they can be inspected, checked and maintained from all sides at all
 times, i.e. there must be unobstructed access to the refrigerant-carrying and electrical components,
 connections and lines, the pipeline labelling must be identifiable and adequate space must be available fortesting.



- The working fluid-carrying lines must be protected against mechanical damage. On-site connections: when installing keep the unit free of load; force must not be exerted on the distribution and headerpipes.
- · The following must be observed without fail when installing the unit:
 - Imperative adherence to spacing from objects that could be endangered by an effect of the CFC/ HFC refrigerant.
 - Provision of measures to safeguard protective objects from a CFC/HFC refrigerant concentration higher than that permitted by EN 378-3.
 - Easily flammable materials must not be placed below the unit.
 - Set up and fix units as follows: In areas that are used for inner-plant traffic, the pipelines to and from the unit must be installed only with connections and fittings that cannot be removed.
 - That when switching over a duty pump to a reserve pump no liquid, cold refrigerant remains in thepump.

2.11 Residual hazards with break during operation

⚠ WARNING

Injuries and damage to property caused by break during operation!

- Defective installation (see Residual hazards caused by defective installation, page 25).
- Non-compliance with maximum permissible operating pressure (see Operating conditions, page 19).
- <u>Disregarding pressurised line sections with maintenance (see Residual hazards caused by pressurised parts, page 24).</u>
- Disregarding residual hazards caused by vibrations (<u>see Residual hazards caused by vibrations</u>, page 24).

result in ruptures during operation and maintenance. This results in dangers caused by

- •escaping materials (see Residual hazards caused by pressurised parts, page 24).
- released working fluid (see Residual hazards due to CFC/HFC refrigerants, page 22).

Ensurethat:

- · The installation is fault-free.
- · The maximum permissible operating pressure is alwaysadhered to.
- Pressurised line sections are de-pressurised before all maintenance and repair work.
- Vibrations from the refrigeration system, from the (vibrations caused by system compressors, , components and lines) and from the fan (imbalances caused by frosting, icing or dirt build-up or damages) are reduced with all available means and brought down to an absolute minimum.
- · Release devices to prevent liquid escapes are provided andavailable.
- Undercooled liquid is only present in the lowest possible amount in system sections in shutdown state – minimized number of "fluid sacks".
- When switching over a duty pump to a reserve pump no liquid, cold refrigerant remains in the pump.

2.12 Residual hazards caused by escaping objects or liquids

MARNING

Injuries and damage to property caused by escaping objects or liquids!

Residual hazards caused by escaping objects and liquids (see Residual hazards with break during operation, page 26).



2.13 Residual hazards with disposal

MARNING

Danger of injuries and damage to property caused by CFC/HFC working fluid, ,!

The following notes are recommendations for the proper professional disposal of the unit. Applicable waste disposal laws are binding for the country of operation:

- Disposal must only be carried out by experts.
- All unit components, e.g. working fluids, refrigerator oil, heat exchangers, fans, must be disposed of properly as specified.
- Used working fluid that is not determined for reuse, must be treated as waste and safely disposed of. There must be no emissions into the environment.
- The CFC/HFC refrigerant must be filled into a special refrigerant container in compliance with the respective safety measures. This special refrigerant container must be suitable for the refrigerant. It must be easy to identify and labelled for the refrigerant, e.g. "HFC R-4304A recovered".
- A disposable single-use container must not be used, as refrigerant vapour residues in the container escape during disposal.
- The working liquid receiver must not be overfilled. The maximum permissible pressure of the working fluid container must not be exceeded during the work process.
- The working fluid must not be filled in a liquid container that contains another or an unknown working fluid. This other or unknown working fluid must not be released into the atmosphere, but rather identified, treated again, or properly disposed of as specified.
- An officially authorised facility can be used for destroying the working fluid.
- Used refrigerator oil that has been recovered from the unit and cannot be treated again, must be kept in a separate, suitable container, treated as waste and safely disposed of.
- It must be ensured that all unit components containing working fluids and refrigerator oil, are disposed of properly asspecified.
- The unit consists predominantly of the basic materials, copper, aluminium, (heat exchangers and casings), steel and aluminium, copper, polyamide (motors), steel, copper, insulating material (heater rods with electric defrosting option; accessory at customer's request). These materials can be handled by the waste industry, including in paint-treated state, to recycling via mechanical and thermal separation.
- Before scrapping the working fluid-carrying unit components must be drained, whereby the pressure must be reduced to at least 0.6 bar absolute for a unit pipe volume up to and including 200 I, and to 0.3 bar absolute for a unit pipe volume over 200 I. The pressure reduction process is then ended when the pressure no longer increases and remains constant, and the unit is at ambient temperature.

↑ **WARNING**

Danger of environmental pollution!

The facility for recovering or disposing of the refrigerant must be operated so that the danger of a refrigerant or refrigerator oil emission into the environment is kept as low as possible.

- Ensure that no working fluid enters water systems or sewage.
- Operate the facility for recovering or disposing of working fluids so that the danger of a working fluid
 or refrigerator oil emission into the environment is kept as low as possible.

Güntner GmbH & Co. KG's transportation packaging is made from environmentally compatible material and is suitable for recycling.



3 Technical data

3.1 **Unit**

NOTICE

The fans' capacity values depend on the ambient temperature and on the air resistance at the set-up point.

Güntner GmbH & Co. KG recommends electric fan ring heating with use in the temperature range.

Please consult the manufacturer when operating the unit below -40°C because of the special material requirements and selection.

All electrical parts must be installed in accordance with EN standards.

Projectnumber	See order-related documents
Unitname	See order-related documents
Manufacturernumber	See order-related documents
Productionyear	See order-related documents
Workingfluid	See order-related documents
Volume	See order-related documents
Maximum permissible pressure (PS)	0 - 32 bar
Testpressure	35.2 bar
Permissible ambient temperature	-30- +30- 60°C (see order-relateddocuments)
Permissible air humidity	>100%
Testdate	See order-related documents
Testmedium	Dryair
Airborne noise emitted	See order-related documents In accordance with the standard procedure for calculating sound level described in EN 13487; Annex C (normative).
Weight	See order-related documents

3.2 Fans

Fantype	See order-related documents
Protection rating	IP54
Currenttype	Rotatingcurrent
Voltage	400 V 3~ 50 Hz Y-/ Δ-can be switched over
Permissible air temperature	Operating range: at least -30°C to +55°C
Externalpressing	Ø 500 mm = 50 Pa
	Ø 650 mm = 100 Pa



4 Set-up and function

The shock froster consists of,

- a heat exchanger, consisting of tube coils fitted with fins (copper tube, aluminium fin), distribution tubes and header outlets (copper) and tube connections to the tube system,
- a casing including legs made of galvanized steel, unpainted
- and depending on the version an axial fan (Ø 500 mm, Ø 650 mm) with maintenance-free motors, arranged in modules of 2, 4, 6 or 8 fans, each 2 above one another.

The shock froster is a refrigeration system component. It provides a finned heat exchanger (straight and curved pipes – pipe coils – with fins, which are connected to form a heat exchanger) in which liquid refrigerant evaporates by absorbing heat from the material to be cooled.

The refrigeration system is a combination of refrigerant-carrying components and fittings connected with one another, which form a closed circuit, in which the refrigerant circulates.

The refrigerant absorbs heat at a low temperature and low pressure and evaporates (evaporator-side), and at a higher temperature and higher pressure gives off the heat again and condenses itself (condenser-side).

The heat from the material to be cooled is dissipated with fans over the entire surface of the evaporator.

The GFN series shock frosters standardly operate in accordance with the "dry evaporation" principle. The refrigerant liquid fed to the evaporator is completely evaporated in it, and overheated to protect the compressor from slugging. The CFC/HFC refrigerants used (R134a, R404A, R407C, ...) are Group L1/A1 refrigerants (see Residual hazards due to CFC/HFC refrigerants, page 22).



5 Fan motor

NOTICE

During longer periods of storage or standstill, the fans must be activated during 2 to 4 hours per month.

NOTICE

For fans with the protection rating IP55 or higher, existing closed condensation water holes must be opened at least once every six months.

AC technology

The AC motors are protected against overheating by a thermocontact (or PTC resistor).

For motors with a thermocontact, the thermocontact must be switched in such a way that the motor cannot be powered on when the thermocontact is triggered. A locking mechanism is recommended to prevent renewed power-on.

Motors with a PTC resistor need an additional external trigger unit for the installed thermistors. A locking mechanism is recommended to prevent renewed power-on. The test voltage at the thermistors is not permitted to exceed 2.5 V, or only current-limiting testdevices may be used.

When using a star-delta connection, a corresponding delay must be considered.

For motors with direct starting and a connection value > 4.0 kW, an inrush current limitation (soft start using a thyristor) could be required.

If frequency converters are to be used for speed control, the following points must be considered for external rotorfans:

Between the frequency converter and fans, all-pole sine-wave filters must always be installed (sine wave-shaped output voltage; filter effect between phase to phase and phase to earth).

All Güntner frequency converters are equipped with this function as standard. Conventional three-phase motors are suitable for direct operation with frequency converters.

With star-delta connection, the three-phase fan motors can be operated with two speeds or with speed control. The direction of rotation must be checked. A change in the direction of rotation, if it is wrong, is made by interchanging two phases.



6 Transportation and storage

6.1 Safety

⚠ WARNING

Crushing danger with fallingdown!

The unit weighs between approx. 215 kg and 935 kg. It can slip and fall off the transporting device, causing serious injuries or death. Heavy impacts or vibrations can damage the unit.

Ensure that the assigned staff is trained for proper unloading.

Ensure that nobody is under the unit or near the loaded area during the transport.

Ensure even weight distribution. Ensure that the bulk of the weight is always on the fan side. Observe the transport labels on the packed unit (see Other signs and notes on the unit, page 15).

Secure the unit against slipping and mechanicaldamage.

When transporting by crane: The hooks and lifting gear of the load lifting equipment must be only attached at the points specified by the manufacturer. Ensure that the unit casing is not crushed by slings.

Use auxiliary transport equipment where required. Use a transporting device appropriate for the unit's weight. You will find the weight of the unit in the order-related documentssee(Set-up and other applic-able documents, page 7). Do not use connection pieces and header pipes as hooking points for lifting, pulling, fixing or mounting. This can cause leaks.

Transport the unit carefully. Particularly avoid setting the unit down hard.


6.2 Transportation and storage

NOTICE

Read and observe all transport signs on the units' packaging!

Prolonged mechanical stresses caused by uneven road surfaces and potholes and vibrations during transport by ship can cause transportation damage. Before transportation by sea or in countries with difficult transport routes, attachment parts that are likely to vibrate – in particular fans and base stands – must be removed for transportation.

- Use suitable equipment to transport the packed unit to the destination installation site (for example, a crane or fork-lift).
- Unload the unit.





6.3 Storage beforeinstallation

NOTICE

Danger of corrosion and dirtbuild-up!

Moisture and dirt must be prevented from entering the unit.

- Protect the unit against dust, dirt, moisture and wetness, damage and other harmful effects. Harmful effects: see Safety instructions for set-up and start-up, page 33
- Do not store the unit for longer than necessary. Only store the units in their original packaging until installation. Always only place packaging units of the same size on top of one another.
- Store the unit at a protected place free of dust, dirt, moisture and damage-free until its set-up (well-ventilated halls or roofed storage site).
- If the unit set-up is delayed with regard to the planned installation time: protect the unit against weather and other harmful effects and dirt and other contaminants with an appropriate cover. The unit must also bewell-ventilated here.



7 Set-up and start-up

7.1 Safety

7.1.1 Safety instructions for set-up and start-up

WARNING

Danger of injuries and damage to property with escaping CFC/HFC refrigerant!

Incorrect installation causes the danger of working fluid escaping when the unit is operated and injuries or damage to property (see Residual hazards due to CFC/HFC refrigerants, page 22).

Follow the set-up instructions in his chapter precisely and apply extreme care!

NOTICE

Damage to the system's!

Foreign materials and contaminants in the working fluid circuit can impair the effectiveness or damage components. Particularly harmful contaminants are:

- Moisture
- Atmosphericair
- Welding and solderingresidues
- Rust
- Soot/ash/cinders
- Metal cuttings
- Unstableoils
- Dust and dirt of all kinds

Moisture in the working fluid-carrying components of the unit can have the following consequences:

- Water separation and ice formation cause faults in the switching and control fittings of the refrigerationsystem
- Acidification
- Ageing and refrigerator oildecay
- Corrosion

Atmospheric air and other non-condensable gases can have the following consequences:

- Refrigerator oil oxidation
- Chemical reactions between working fluid and refrigeratoroil
- Increased condensing pressure in thesystem

Chemical reactions between working fluid and refrigerator oil with the absence of moisture or atmospheric air with ageing and working fluid and refrigerator oil decay can have the following consequences:

- Formation of organic and inorganicacids
- Increased compressed gas temperature in the system
- Corrosion
- Bad lubrication, increased wear and tear through to system or failure

Other contaminants cancause:

- Accelerated chemical processes (decomposition)
- Mechanical and electrical faults in the refrigeration system



During the installation (connecting the working fluid-carrying components of the unit to the working fluid-carrying system of the installation's ensure that internal contamination is strictly avoided.

Perform the installation with extreme cleanliness.

Finish all on-site pipe installation work before releasing the transportpressure!

Only release the transport pressure on the Schrader valve immediately beforeinstallation.

Only remove the sealing caps on the distribution and header pipe immediately before installation.

NOTICE

Danger of corrosion and dirtbuild-up!

Moisture and dirt must be prevented from entering the unit. If moisture and dirt penetrate the unit there is also the danger of damage to fittings and other system components of the .

Protect the unit against dust, contamination, moisture and wetness, damage and other harmful influences. Harmful influences are, forexample:

- Mechanical: Damages caused by impacts, objects falling on or against, collisions with transport equipment, etc.
- Physical: Damages caused by close by concentrated flammable gases
- Chemical: Damages caused by contaminated atmospheres (salt, acid, chlorine, sulpher-containing, orsimilar)
- Thermal: Damages caused by close by heat sources

Begin with the installation as soon as possible.

MARNING

The electrical installation may be performed only by electricians (or by expert technicians with appropriate qualifications) in compliance with the relevant VDE rules (or applicable national and international regulations) and the TCCs of the EPCs!

7.1.2 System-side safetyrequirements

The unit is a component of an installation and can only be operated in conjunction with the installation

- All equipment required for operating the unit must be integrated into the switching and activation equipment:
 - Electrics: Fans and other electrical components
 - Working fluids: valves and fittings
 - Drip water: drip water drain line
- The working fluid-side and electrical connections must be available on the system. The connections must be specified in the order-related documents.
- The working fluid-side and electrical connections must be available for the unit on the cooling unit. The connections must be specified in the order-related documents.
- The power supply of the fans must be provided in acc. with the specifications on the type plate on the fan motors.
- A switch-off device for preventing unexpected start-up (repairs switch), which separates all active conductors from the power supply (all-pole switch-off), must be provided for the fans in acc. with EN60204-1.
- The fans' switch-on/off device must be secured (e.g. with a padlock) to prevent uncontrolled fan start-up.



- The electrical motor, repairs switch, terminal box and switching cabinet connections must be provided in acc. with the respective connection diagrams.
- It must be possible to shut off the unit if a leak occurs.
- People wearing ambient air-independent breathing apparatus in full protective clothing must also be able to activate all safety-relevant shut-off fittings.
- It must be possible to activate all devices meant for diverting escaping working fluids from a safeposition.

7.1.3 Customer-side safety precautions

MARNING



Danger of injuries!

The unit contains CFC/HFC refrigerant (see Residual hazards due to CFC/HFC refrigerants, page 22).



The CFC/HFC refrigerants that are used (R134a, R404A, R407C, R507, R22 ...) are Group L1/A1 refrigerants classified according to their flammability (L) and toxicity (A) in compliance with EU Directive 2014/68/EG for pressure equipment (Pressure Equipment Directive):

 Refrigerants that, when gaseous, are non-flammable irrelevant of their concentration inair.



Refrigerants with a time-weighted, averaged concentration that have no adverse
effects on the majority of staff that are exposed every day during a normal 8 hour
working day and a 40 hour working week to this concentration, which is greater
than or equal to 400 ml/m³ (400 ppm (V/V)).

There is no imminent danger for the staff. However, refrigerants of the Group L1/A1 are generally heavier than air and may flow off to rooms on a lower level. In still air there may be an increase of the ground level concentration. With high concentrations there is a danger of suffering from disordered cardiac rhythm and suffocation due to a reduced oxygen concentration, especially at groundlevel.

Unauthorised people must not have access to the unit. Please ensure that CFC/HFC refrigerant escaping from the unit cannot reach the interior of the building or put people at risk in any other way.

Comply with the requirements of EN 378-3 for refrigerants, filling weight and cold transfer systems.

Install the unit in accordance with EN 378-1 only in the commissioned configuration and only in a set-up room that the unit manufacturer has configured the unit for. Install the unit in accordance with EN 378-3, section 5 in a special machine room if an explosion or a CFC/HFC refrigerant concentration of more than that permissible under EN 378-3 could endanger the work environment. Take effective protective precautions if such a spatial separation were to be required, but is not possible.

Install the electrical equipment (for fan operation, for ventilation, for lighting and for the alarm system) in the set-up room while observing the condensing-out of moisture and drip water formation, as well as the risk level of CFC/HFC refrigerant in accordance with EN 378-3; section6.

Arrange CFC/HFC refrigerant detectors and alarm systems to warn of explosion or fire dangers and CFC/HFC refrigerant concentrations that are hazardous to health



and for control purposes in the unit set-up room in accordance with EN 378-3; section 7.

Ensure that the device in the set-up room is not exposed to any inadmissible high temperature effects. Effectively protect the unit against heat sources or temporary high temperatures.

↑ WARNING

Danger of environmental pollution!

- Ensure that no refrigerant enters watersystems orsewage.
- Operate the facility for recovering or disposing of refrigerant so that the danger of a refrigerant or refrigerator oil emission into the environment is kept as low as possible.


7.2 Requirements at the set-uppoint

You will find the dimensions and weights in the order-related documents.

- Position the unit so that it cannot be damaged by internal traffic or transport processes.
- ▶ Enable optimum unit control and accessibility:
 - Place the unit so that is can be monitored and controlled from all sides at all times.
 - Ensure that sufficient space is provided for maintenance.
 - Ensure that all liquid-carrying components, connections and lines and all electrical connections and lines are easy to access.
 - Ensure that there is free space for the unobstructed exchange of heater rods for electric defrosting.
 - Ensure that the pipes'identification is well visible.
 - Ensure that units with electric block defrosting have enough space for changing heater rods.



7.3 Unpacking the unit




- Remove unit leg bolts on timber (8).
- Remove unit leg bolts on timber (7).
- Remove unit from packaging: When lifting insert the forks under the unit frame, as this protects the driptray.



- Check the delivery for completeness. You will find a list of the contents of the package in the order-related documents.
- Any transport damage and/or missing parts must be recorded on the bill of delivery. The facts must be immediately reported to the manufacturer in writing. Damaged fins can be straightened on-site with a fin comb.
- ▶ The units are delivered packed in the installation position.
- Check transport overpressure: The units are delivered from the manufacturer with approx. 1 bar transport overpressure (cleaned and dried air). Read the transport pressure on the Schrader valve (pressure measurement). With unpressurised unit: Immediate report to manufacturer and noting on bill of delivery. An unpressurised unit indicates a leakon the unit!

CAUTION! Danger of injuries and damage to property with escapingworkingfluid! An unpressurised unit indicates a leak due to transport damage. Escaping workingfluid through leaks on the unit can cause injuries or (see Residual hazards due to CFC/HFC refrigerants, page 22). Do not put the unit intooperation!

- Check transport pressure and release (only immediately before installation).
- Remove blanking plugs.



1: Check/release transport overpressure / 2: Remove blanking plugs.

NOTICE

Danger of corrosion and dirt build-up!

Moisture and dirt must be prevented from entering the unit.

Protect the unit against dust, dirt, moisture and wetness, damage and other harmful effects. Harmful effects: see Safety instructions for set-up and start-up, page 33

Begin with the installation as soon as possible.

7.4 Installation

7.4.1 System-side requirements for stress-freeinstallation


- Prevent stresses in the unit:
 - ° Ensure that all fixing points have the same spacing to the fixing level.
 - Ensure that all fixing points maintain the same spacing to the fixing level under load and permanently.
- ▶ Set up and fix units as follows: Airflow must not be impaired by obstructions.



- The units must be installed on fixing points that are appropriate for the unit's weight and then bolted with fixing bolts. The operator or installer of the equipment is responsible for ensuring that the bolted connections are of an adequate strength. The following instructions must be observed when fixing the units:
 - The diameter of the mounting holes have been statically determined by the manufacturer; the fixing bolts must be adapted accordingly. When calculating the transferring bearing strength it is imperative to take into account the total weight of the unit (= structural weight + weight of pipe content + additional weight, such as water, frost, ice, dirt or similar).
 - The fixing bolts must be secured against loosening with an appropriate locking device.
 - The fixing bolts must not be overtightened or stripped.
 - All fixing bolts must be tightened equally.
- Prevent the unit from shifting in its position. Fix the unit in its position. Tighten the fixing bolts and secure then against loosening.



- Ensure that the drip water drains correctly. Set up the unit horizontally with a sufficient slope for the drip water run-off. The units are delivered in the installation position with mounted drip tray.
- Only fix the unit to the intendedfixing points.



1 Fixing of unit

7.4.2 Mounting theunit



7.5 Notes on connecting the unit

MARNING

Danger of injuries and damage to property with escaping CFC/HFC refrigerant!

Incorrect installation risks working fluid escaping when the unit is operated, causing injuries or damage to property (see Residual hazards due to CFC/HFC refrigerants, page 22).


Prevent working fluid from escaping from the unit into the environment.

- · Secure all working fluid-carrying lines against mechanical damage.
- In areas that are used for internal traffic, only lay the pipelines to and from the unit with connections and fittings that cannot be removed.

Ensure that the on-site connections do not exercise any forces upon the distribution and header points. This can cause leaks on the working fluid connection points of the unit and on connection points of the on-site pipe-laying.

7.5.1 Connecting the thermostatic expansion valve

The expansion valve and the heat carrier distributor are connected to the system as follows:



NOTICE

After mounting, check that the capillary tubes of the refrigerant distributor are not blocked.

Vibration can cause mechanical damage and leaks.

It is important to carefully position the capillary tubes, if necessary using e.g. plastic cable ties to fasten them in place, to prevent vibration causing them to collide with one another or with other objects.




7.5.2 Connecting the drain line to the drip tray

- Lay drain line completely strain-free. The diameter of the drip water drain line must be at least that of the drip water drain of the unit, and the drip water drain line should be laid with a slope (3 –5°).
- ▶ Tighten connection nuts with the handonly!

NOTICE

Danger of damaging! The plastic threads can be damaged by over-tightening if you use a wrench. This results in leaks with drip water damage on the produce to be cooled. Do not tighten the connection nuts with awrench!



7.5.3 Connect the unit to the system

M WARNING

Danger of injuries and damage to property!

Improper connection to the the system causeshazards:

- Leaks result in escaping CFC/HFC refrigerant (see Residual hazards due to CFC/HFC refrigerants, page 22).
- Soldering and welding work on pressurised parts can result in fires or explosions.
- Smoking or open light can cause fires due to the presence of refrigerator oil.
- Ensure that stresses and vibrations from the system are not passed on to the unit.
- Only lay working fluid-side connections stress-free! The on-site pipeline system must be braced before connecting to theunit!
- Soldering and welding work is only permitted on unpressurised units!
- · Evacuate the unit professionally in acc. with EN 378-2.
- The use of open fire at the installation site is forbidden. Fire extinguishers and extinguishing agents
 used to protect the equipment and the operating staff must comply with the requirements of EN
 378-3.
- Ensure that refrigerant detectors and alarm systems for warning about fire dangers, about healthendangering concentrations and for control purposes at the unit set-up point are arranged in acc. with EN 378-3; section7.




- Install the pipes in acc. with EN 378-1 and EN 378-3. Ensure here:
- Release devices to prevent liquid escapes must be provided and available.
- That in shutdown state under-cooled liquid is only present in the lowest possible amount in system sections minimized number of "fluidsacks".
- That the pipeline installation is kept as short as possible. Use as few bends as possible, and if bends are necessary, use bigradii!
- Avoid transmitting vibrations to the unit via conduits or pipes. If necessary, use vibration dampers.
- Always lay the fluid supply and return lines separately from one another. Make sure they do not touch.
- It must be possible to shut off the unit if a leak occurs. It must be possible to activate all devices used for diverting escaping working fluids from a safe position.
- With connection of the liquid and suction line, the thermostatic expansion valve, including its overheating sensor, must be protected against high heat stresses from the soldering process!
- Observe the following when soldering:
 - All connections must behard-soldered!
 - ° Caution! Use silver solder with TS < -40 °C! Ask manufacturer about solder specification if required!
 - Avoid percussive soldering joints; use copper pipe ends that are widened on one side (capillary soldering)!
 - ° Prevent leaks, solder precisely and carefully!
 - ° Prevent overheating when soldering (danger of excessive scaling)!
 - Use shielding gas when soldering (prevent excessive scaling)!

7.5.4 Unit electrical connection and protection

All fans with rotating current drive can be operated via D-S switch-over with two different speeds:

- · D: highspeed
- · S: lowerspeed
- Connect fan motors in acc. with motor connection circuitand check connection.
- Provide power supply in acc. with the specifications on the fan motor's type plate:
 - The fan motors for the 500 mm and 650 mm fan diameters are operated in 3~ rotating current and can be operated star/delta connected as required.
- Connect thermo contacts for motor protection.
- Where required, connect electrical feeds for the heater rods for electric defrosting in accordance with electric connection diagram.



- Defrost limit sensor position (if used)
- 2 Electrics (fan motor, stamp data, connection values)



Seal all electrical lines to the connection boxes in acc. with their protection class. The connection class is specified in the order-related offer documents.

MARNING

Danger of damaging! If the fuse rating is too high there is the danger of injuries to people and damage to property.

Max. fuse rating for the defrost heater rods feed : see order-related offer documents. The supply lines must always be fused as appropriate for the smallest wire cross-section.

7.6 Perform acceptancetest

Danger of injuries and damage to property!

Escaping CFC/HFC refrigerant can cause injuries or even death (see Residual hazards due to CFC/ HFC refrigerants, page 22).

Perform the following acceptance test with an expert before starting up the unit after making important changes and after aunit exchange.

- Ensure that the temperature and air humidity at the set-up point are in line with the technical data (see Technical data, page 28).
- Ensure that sufficient air can be sucked in and released.
- Ensure that the supply feed is sufficient for the required energy. Compare the unit inside of the systemwith the plans of the systemand the electrical wiring diagrams.
- Test the unit for vibrations and movements that can be caused by the fans and operation of the system . Remove oscillations, vibrations and movements following consultation with the manufacturer or independently.
- Perform visual inspection of the structural design, the brackets and fixtures (materials, sequence, connections), the ability to operate and the arrangement of the fittings.
- Check and if necessary re-tighten all threaded connections, especially on the fans.
- Check installation of pipe connections.
- Check laying of working fluid-carrying connection pipes.
- Ensure that the unit is protected against mechanical damage.
- Ensure that the unit is protected against inadmissible heating up and cooling down.
- Check the fan bladesprotection.
- Ensure that optimum unit control and accessibility are guaranteed.
 - Is the unit placed so that it can be monitored and controlled from all sides at all times?
 - Is sufficient space provided for maintenance?
 - Are all liquid-carrying components, connections and lines and all electrical connections and lines easy to access?
- Are the pipes easy toidentify?
 Check heat exchanger surfaces for dirt and clean as required (see Clean unit, page 55).
- Perform function tests on the fans (rotation direction, power consumption, etc.).
- Check electrical connections of the fan motors and, where app., the heater rods with electric defrosting for damage.



- Check the soldering and welding connections, the electrical connections and the fixture connections
- Perform pressure test with test gas and with a test pressure of 1.1-times the permissible operating pressure: check the connection seals and detect leaks, e.g. with foaming agent, or similar.
- Check corrosion protection: Perform a visual inspection on all bends, components and component holders that are not heat-insulated. Document and archive test results.
- ▶ Perform test run. Observe and check unit during test run, in particular for:
 - Fan smooth running (bearing noises, contact noises, imbalances, etc.).
 - Fan powerconsumption:
 - Leaks
- Report all defects to the manufacturer immediately. Remove defects following consultation with the manufacturer.
- Check the unit and the unit's interaction with of the system again after 48 operating hours, especially on the connections and on the fans, and document thetest results.

7.7 Test readiness for operation

- Ensure that all electrical protective measures are ready to function.
- Ensure that all working fluid-carrying connections are securely in place.
- Ensure that all electrical connections (fans, if applicable heater rods for electrical defrost) are effected securely.
- Ensure that the unit connection to the drip water drain line is properly set up (see Connecting the drain line to the drip tray, page 42).

7.8 Putting the unit into operation for the first time

M WARNING

Danger of injuries and damage to property!

Escaping CFC/HFC refrigerant can cause injuries or even death (see Residual hazards due to CFC/HFC refrigerants, page 22).

You can put the unit into operation, only when:

- The unit has been properly mounted and connected (see Installation, page 38).
- You have performed a complete acceptance tesste(ePerform acceptance test, page 44).
- You have checked the unit's readiness for operationse(e Test readiness for operation, pag4e5).
- All safety precautions (see Safety, page 33) have beentaken.

Follow the operating instructions manual of the system!

Contact the manufacturer immediately if you want to operate the unit under different operating conditions as those defined in the order-related offer documents.

- Switch on the system including of the electrical system (see system).
- Activate theunit:
 - Open the valves on the inlet and outlet-side system.
 - Activatefans
 - Put drip water waste line into operation



Wait until the operating point is reached. After the operating point is reach the unit is ready to operate (see system).

Parameters for setting the operating point, see order-related offer documents.

Operatingpoint:

- Evaporation temperature
- Airflowvolume
- · Air inlettemperature
- · Relative air humidity

To ensure the specified operating point is complied with the actuators for the operating point setting must be secured against unauthorized access (e.g. by sealing, screwing on caps, removing hand wheels, etc.).



8 Operation

8.1 Safety

↑ WARNING

Danger of cutting off, pullingin!



There is a danger of cutting off fingers on the rotating fan blades, injury hazard for the hands and pulling in danger with loose elements such as hair, necklaces or clothing parts.

Do not operate fans without guardgrille!

MARNING

Danger of frostbite/burning!



Danger of frostbite or burns if the parts are touched (<u>see Thermal residual hazards</u>, page 22).

Do not touch any parts of the unit without protective gloves when the unit is in operation or if it has not yet warmed up or cooled down after operation.



8.2 Putting the unit into operation

To operate the unit the systemincluding the electrical system must be in operation. The unit must be started up by opening the valves on the inlet and outlet side of the plantby connecting it to the electrical system and the drip water drain as described below (see system operating instructions manual):

- Switch on electrical system
- Open working fluid-carryinglines
- Switch onfans

8.3 Taking the unit out of operation

The units are system components of a system. The unit is taken out of operation by switching off the system in accordance with the system operating instructions manual. The working fluid-carrying lines of the plant must be shut off here and the fans and, where applicable, the heater rods for electric defrosting must be disconnected from the electrical system (see system) operating instructions manual:

- Switch fansoff
- Switch electrical systemoff



- Close working fluid-carrying lines
- NOTE! When shut down consider max. operating pressure! If necessary, take precautions to ensure that it cannot be exceeded, or drain the device.

NOTICE

With shutdown times of a month or longer put the fans into operation for approx. 2-4 hours a month to maintain their functionality.

8.4 Shutting the unitdown

M WARNING

Danger of injuries and damage to property!

Escaping CFC/HFC refrigerant can cause injuries (see Residual hazards due to CFC/HFC refrigerants, page 22, and see Residual hazards caused by pressurised parts, page 24).

Ensure that the maximum operating pressure is not exceeded after the shutdown either!

NOTICE

Danger of corrosion and dirt build-up!

Moisture and dirt must be prevented from entering the unit.

Protect the unit against dust, contamination, moisture and wetness, damage and other harmful influences (see Safety instructions for set-up and start-up, page 33).

With shutdown times of a month or longer put the fans into operation for approx. 2-4 hours a month to maintain their functionality.

- Take the unit out of operation (see Taking the unit out of operation, page 47).
- Secure the unit:
 - When shutdown consider max. operating pressure (<u>see Technical data, page 28</u>)! If necessary, take precautions so that it cannotbe exceeded.
 - Secure the fan motor drives and, where applicable, the heater rods with electric defrosting against switching on again.
 - Secure working fluid-carrying lines against pressurizing with working fluid.
 - Protect against damaging effects at the set-up point or intermediate storage location (see
 Safety instructions for set-up and start-up, page 33), so that the unit's components are kept
 properly looked after and the proper intentional use and usability of the unit are maintained.
 The corresponding storage conditions must be provided for this (see Storage before installation, page 32); precautionary corrosion protection measures, regular checking of the fans'
 functionality and regular checks on the shutdown unit.
- Evacuate the unit: Completely release working fluid and, if applicable, refrigerator oil (see Residual hazards with disposal, page 27).



8.5 Putting the unit into operation after a shutdown

The unit must be put back into operation after a shutdown in acc. with the system-specific set-up in acc. with the operating instructions manual as follows:

- Test the unit's readiness for operation (see <u>Test readiness for operation, page 45</u>). Perform pressure test and visual inspection for corrosion protection.
 - NOTE! The pressure test with recommissioning must only be carried out with appropriate media at appropriatetestpressure.
- ▶ Put the unit into operation (see Putting the unit into operation, page 47).

8.6 Changing the unit over to another working fluid

MARNING

Danger of injuries and damage to property!

Considerable dangers can be caused with operation with another working fluid without prior manufacturer approval (see Improper use, page 19).

Without prior written consent from Güntner GmbH & Co. KG, the unit must not be changed over to use a different workingfluid.

- ▶ Ensure that the unit manufacturer has agreed to the changeover.
- Ensure that the right working fluid is re-filled. Ensure that all materials used in the unit are compatible with the new working fluid.
- Ensure that the permissible pressure is not exceeded.
- Check that the new working fluid can be used without requiring a new test certificate for the unit. Ensure that classification is complied with.
- The safety device for the unit must be swapped out or reset.
- Mixtures with residues of working fluid and oil, for example, must be prevented.
- All information concerning the new working fluid must be changed accordingly.
- ► The complete documentation, including these operating instructions and the system operating instructions manual must be changed accordingly.
- Perform acceptance test (<u>see Perform acceptance test, page 44</u>).



9 Troubleshooting

9.1 Safety

MARNING

Danger of injuries and damage to property!

Faults that are not described in these operating instructions may be resolved only by Güntner. Contact the Güntnerhotline.

Faults that are described in these operating instructions must only be removed by appropriately trained personnel (see Personnel, care requirements, page 18).

If any faults occur during the operation, monitoring or maintenance of the system as a whole, inform Güntner GmbH & Co. KG immediately.

9.2 Service

Tel. +61 1300BITZER

Emil: customerservice.sydney@bitzer.com.au

9.3 Troubleshootingtable

Fault	Possiblecause(s)	Remedy		
Fan motor not	Power supply interrupted	Restore powersupply		
running	Fan bladestuck	Enable fan to rotatefreely		
Bearingnoises	Defective fan motor	Renew bearing or fanmotor		
Unitvibrating	Defective fan blades	Change fan blades		
	Loose fanfixture	Tightenfixtures		
Unit capacitynot achieved	Heat exchanger is very dirty, frosted, iced on the air side	Clean, defrost heatexchanger		
	Fans not running properly or down	Repair, exchangefans		
	Working fluid pressurising defective (temperature and quantity insufficient)	Set working fluid pressurising values (temperature and quantity) to reference values.		
Working fluides- caping	Unit working fluid-carryingcomponentsleaking	Switch off working fluid feed and fans, closeleak		



10 Maintenance

10.1 Safety

10.1.1 Before starting all maintenance

MARNING

Danger of injuries and damage to property with escaping working fluid! see Residual hazards due to CFC/HFC refrigerants, page22).

Only perform maintenance work – especially welding work – on the leaking unit after completely removing the working fluid from the leaking unit!

Perform the following safety measures before beginning all maintenancework:

- drain the unit's heat exchanger
- Clean and blow out the unit's heat exchanger.

10.1.2 With all maintenance work

WARNING

Danger of injuries and damage to property with escaping CFC/HFC refrigerant! Escaping refrigerant with leaks on the evaporator can cause the following hazard situations and injuries:



Warning against explosion-risk and fire-risk substances in the set-up room! Unintentionally carried in oil residues canignite.

- Ensure that there is no unintentionally carried in oil in the set-up room.
- · Keep the risk area free of direct and indirect ignition sources.
- Before releasing for maintenance obtain the required approvals for work for the unit that can involve ignition sources (e.g. grinding, welding, soldering, etc.).
- With all work involving ignition sources (e.g. grinding, welding, soldering, etc.) in the work area, keep suitable fire extinguishing equipment that meets the requirements of EN 378-3 at hand.
- Do no bring any open flames or hot gases (e.g. candles, matches, welding beads, welding sparks, glowing cinders or tobacco) into the set-uproom.
- Ensure that there are no warmed up or hot surfaces (e.g. heaters, hotplates, bulbs, motor housings) in the set-uproom.
- Ensure that no frictional heat develops in the set-up room (e.g. overheated stores).



Warns against health-endangering irritants in the set-up room! CFC/HFC refrigerant under defervescence still present can evaporate. Inhalation of refrigerant vapour causes harmful to health irritations and lack of oxygen.

- Escaping refrigerant vapour and escaping refrigerant liquid must not reach adjacent rooms, staircases, yards, passages or drainagesystems.
- Use respiratory protection.
- Use a room air-independent breathing apparatus with maintenance work in high CFC/HFC refrigerant concentrations in the room air.
- · Ensure the set-up room is wellventilated.
- Divert escaped refrigerant vapour and escaped refrigerant liquid safely.





Warns against cold!

Still present CFC/HFC refrigerant under defervescence has a temperature of 0 °C. Contact with refrigerant under defervescence caused by spraying causes frostbite.



Use eyeprotection!



Use handprotection!

- Ensure that the unit in question is pressure-free before maintenance work begins or the working fluid is sucked up from the unit in question.
- · Power off the electrical system and secure it against unintentional switching on again.
- · Separate the unit to be maintained from the refrigeration system and secure it.

NOTICE



Danger of damage to property!

With work in the inlet and outlet feeds of the fans and heat exchanger, objects can get into the fans and therefore cause faults and damage on the components.

- Power off the fans and, where applicable, the heater rods with electric defrosting before beginning maintenance work and secure them against switching on again.
- After the work has finished do not allow any objects to get back into the inlet and outlet feeds of the fans or the set-up room.

10.1.3 After all maintenancework

⚠ WARNING

Danger of injuries and damage to property with escaping CFC/HFC refrigerant! <u>see Residual hazards</u> <u>due to CFC/HFC refrigerants</u>, <u>page 22</u>)!

Perform the following safety measures after finishing all maintenancework:

- Ensure the switching and activation devices, the measuring and display devices and the safety devices function properly.
- · Ensure the working fluid fittings arefunctioning.
- Ensure that the swivel fan units (optional) and the hinged side covers are fixed in their original position and secured against unintentional or unauthorised opening.
- · Check the identification of the pipelines and ensure this is visible and legible.
- Check the fixing and corrosion protection of the components in question.
- Ensure the electrical connections (e.g. fans and, where applicable, the heating rods with electrical defrosting) arefunctioning.



- Ensure the temperature and air humidity at the set-up point are the same as that in the order-related offerdocuments.
- Perform a pressure test and a tightness test (see operating instructions manual annex).
- Perform an acceptance test (see Perform acceptance test,page 44).
- Perform a pressure test (see operating instructions manualannex).

10.2 Inspection and maintenanceplan

The checks to be performed are listed in the following sections as time-scaled checklists.

10.2.1 Fans

The manufacturer's operating specifications take priority for this component. Güntner GmbH & Co. KG recommends proceeding according to the following inspection and maintenance plan:

d = daily, w = weekly, m = monthly, y = yearly				
Work to beperformed	d	w	m	у
Check the fan drive for smooth running. Vibrations on the unit: remove imbalances Where required, tighten and correct blade fixtures and blade settings				X *
Fan bearing: Running sound and smoothness changes • Exchange bearing				X *
Fan motor: Is a new bearing due? Exchange bearing or motor; where applicable, clean and repair motor				X *
Fan wheel: corrosion on bolts (with threadedblades) • exchangebolts				X *
Fan blades: Corrosion or damage on blades • Exchange blades or wheel				X *

^{*)} Recommended: every six months

10.2.2 Unit heatexchanger

MARNING

Danger of injuries and damage to property with escaping CFC/HFC refrigerant! <u>see Residual hazards</u> <u>due to CFC/HFC refrigerants</u>, <u>page 22</u>)!

d = daily, w = weekly, m = monthly, y = yearly				
Work to beperformed	d	w	m	у
Check heat exchanger for dirt, frost and ice build-up.				X*
With dirt build-ups: Clean heat exchanger (see Clean unit, page				
<u>55).</u>				
With frost and ice build-ups: Defrost the unit (see Defrosting the				
<u>unit, page58).</u>				



d = daily, w = weekly, m = monthly,y = yearly				
Work to beperformed	d	W	m	у
Check heat exchanger's general condition. • Damage found: Repair damage				X*
 Check heat exchanger's operating point (see Operation, page 47). Change in fan capacity found: restore required system-side conditions. Change in surface temperatures found: restore required system-side conditions. 				X*
Check heat exchanger and connections for tightness.				Х
Repair unit sections (<u>see Remove leaks, page 55</u>).				*
Check heat exchanger for working fluid pressurising. Restore required system-side conditions.				Х
Check heat exchanger for corrosion. Corrosion or damage on core tubes, fins, support structures, tube connections, fixtures: repair unit sections affected.				X *

^{*)} Recommended: every six months

Care and maintenanceplan

Measure	Cleaningagent	Interval
Remove frost and clean component	Mechanically	As required (visual inspection)
Heat exchanger defrosting	Hot gas, electric; automatic defrosting device	According to local conditions (penetrating moisture, airor chilled goods); with an ice thickness of 1 mm at the latest.
Complete cleaning	Warm water orenvironmentally safe cleaningagent	After 120 hours
Leakcheck		After 6 months
Corrosion protectioncheck		After 6 months
Clean the heat exchanger (only applies to units with the HydroSpraysystem) Clean the heat exchanger (only applies to units with the HydroSpraysystem)	see Hydraulic cleaning,page 56	Monthly



10.3 Maintenancework

10.3.1 Removeleaks

⚠ WARNING

Danger of injuries and damage to property with CFC/HFC refrigerant (see Residual hazards due to CFC/HFC refrigerants, page 22)!

- · Have leaks removed as quickly as possible by an expert.
- Do not fill with a working fluid other than that specified in acc. with the order-related offer documents!
- · Only put the unit back into operation when all leaks have been repaired.
- Perform all work including pressure, acceptance and functional test (see Perform acceptance test, page 44, and see Test readiness for operation, page 45).

10.4 Cleanunit

10.4.1 General

The following applies for cleaning: The operator must ensure that the cleaning agents are environmental friendly and compatible for the materials in the system. Harmful to the environment substances, e.g. acid-forming, are forbidden.

ACHTUNG - ATTENTION - ATTENTION - ATE

Bei der Verwendung von When cleaning agents
Reinigungsmitteln in are used inside the cold
Kühlräumen, ist auf die room, the corrosion
Korrosionsbeständigkeit resistance of the cooler
Materialien des materials to the applied
Kühlers gegenüber dem cleaning agent has to be
verwendeten Reinigungs-observed!
mittel zu achten!

Lors de l'utilisation des Cuando se apliquen détergents dans les agentes limpiadores en chambres froides, il faut los productos instalados observer à la résistance à en cámaras frías, se der la corrosion des debe tener cuidado que matériaux de l'appareil qui entrent en contact direct avec les la construccióndel détergents.

- Clean casing by rinsing with warm water (approx. +25°C) and/or with environmentally friendly cleaning agents.
- Rinse thoroughly with water after using cleaning agents.
- Allow casing to dry completely.
- ▶ Check working fluid-side and electrical connections (see Test readiness for operation, page 45).

10.4.2 Clean and defrost heat exchanger

- Drain the unit (see system).
- Shut off the unit (see system).
- Power off the fans (seesystem).



- Perform defrosting (see system).
- Clean the heat exchanger with one of the following procedures:
 - Cleaning with compressed air (see Cleaning with compressed air, page 56).
 - Hydraulic cleaning (see Hydraulic cleaning, page 56).

NOTICE

Danger of damage to property!

The fins can be damaged with too high a pressure, too small a distance or a cleaning jet that hits the fins at an angle. Mechanical cleaning with hard objects (e.g. steel brushes, screw drivers, or similar) damages the heatexchanger.

- Use a pressure of max. 50 bar with hydraulic cleaning and max. 80 bar with cleaning with compressed air!
- Maintain a minimum distance from the fins of 200 mm!
- Always aim the jet vertically (max. ±5 degree deviation) at the fins!
- Do not use any hard objects when cleaning!
- Switch fans on (see system).
- Open suction side (see system).
- Open working fluid feed (see system).

10.4.2.1 Cleaning with compressedair

Blast heat exchanger (max. 80 bar pressure) with compressed air to remove dirt and contaminants.

NOTE! Hold the jet of the cleaner vertical to the fins (max. deviation of ± 5 degrees) to prevent fins frombending.

10.4.2.2 Hydraulic cleaning

M WARNING



Warns against dangerous electrical voltage!

Direct and indirect contact with voltage-carrying parts of motors and electrical lines can cause serious injuries or death. Water and cleaning agents conductelectricity.

 Power off the fans for cleaning with water or steam jendwhere applicable the heater rods for electrical defrost and ensure them against switching on again.

NOTICE


Danger of damage to property!

Water or steam jets can damage fans, electrical lines or other components.

- Ensure that electrical connections and motors, as well as components and stored goods at the setup point are not touched by water or steam jets. Cover these if required.
- Heavier moisture or greasy dirt must be removed with a high-pressure water jet (max. 50 bar pressure), steam pressure jet (max. 50 bar pressure), min. 200 mm distance with flat jet nozzle, or using neutral cleaning agent where applicable, always against the airflow direction. Ensure here:



- With oily and greasy dirt it helps to add a cleaning agent to the water.
- When applying chemical agents ensure that they are not aggressive towards the unit's materials. Rinse the unit off after the treatment.
- Cleaning should be done from inside to the outside (but always opposing the dirt onset) and from top to bottom, so that the dirt can be removed without returning.
- Hold the jet of the cleaner vertical to the fins (heat exchanger max. deviation of ±5 degrees) to prevent fins from bending.



Continue cleaning until all dirt has been removed.

10.4.3 Cleaningfans

↑ WARNING

Danger of cutting off, pullingin!

There is a danger of cutting off fingers on the rotating fan blades, injury hazard for the hands and pulling in danger for loose elements such as hair, necklaces or clothing parts.

- Power off the unit before you begin maintenance work. Secure the unit against unintentional switching on again by removing the electric fuses for the unit. Secure the unit with a suitable warning sign referring to unintentional switchingon.
- Put fans and guard grilles that were removed or opened for maintenance back into their original status without fail before you put the unit back into operation!

Dirt build-ups and frost and/or icing on the fans and the fan guard grilles must be removed regularly, otherwise they will cause imbalances or destruction and power losses. The fan motors themselves are maintenance-free.

- Power off the unit and secure it against unintentional switching on.
- Clean fans with one of the following procedures:

NOTE! Danger of damage to property! Mechanical cleaning with hard objects (e.g. steel brushes, screw drivers, or similar) damages the fan. Forbidden!



- Cleaning with compressed air: Blow fans with compressed air (max. 10 bar pressure; min. distance 200 mm) to remove dirt and contaminants. Continue cleaning until all dirt has been removed.
- Cleaning with compressed air and brushes: Remove dry dust or dirt with a brush, a hand brush or with compressed air (max. 10 bar pressure, min. distance of 200 mm) or with a powerful industrial vacuum cleaner. Ensure here: use soft brushes (no steel brushes or similar)! Continue cleaning until all dirt has been removed.
- Mount guard grille
- Switch uniton

10.5 Defrosting theunit

10.5.1 Notes ondefrosting

MARNING

Warning against personal injury and damage to property!

Danger of falling unit parts, masses of water or ice when the drip tray is flapped out.

Nobody is allowed to be in the danger area below the unit during cleaning or maintenance work. The drip tray can be flapped down for cleaning and is protected from falling down by a safety catch. Unit parts, masses of water or ice can nonetheless fall down when it is flapped down.

Defrosting the unit at the correct times guarantees continuous operational reliability and the prevention of inaccessibilities that could result in a shutdown and disruptions. As the local conditions have a very big influence of the unit's performance and the need for defrosting, the operation must be checked regularly and specifically for frost and/or icing on the heat exchanger. The following notes apply for defrosting the unit:

- Regularly check for frost and/or icing. With a frost thickness of max. 1 mm per fin side the unit
 must be defrosted to be able to guarantee fault-free operation.
- Defrosting process must start ingood time.

The defrosting frequency depends on the effects of penetrating moisture (e.g. cold storage room door) or introduced moisture (e.g. goods to be cooled, .). It must be noted here that the temperature difference between the working fluid and the air inlet temperature is critical for the defrosting frequency:

- · Unit with greater temperature difference: Frequent defrosting
- Unit with lesser temperature difference: Less defrosting

Alternating operating states, e.g. usage changes at the set-up point, must also be considered. The defrosting frequency can be influenced by effects on the air side. Insufficient unit-wall distance, distance between two opposing units too low, underdraughts shortly before the air outlet, incorrect goods storage (too high, no wall distance, across the airflow direction) cause increased defrosting frequency.



Defrosting completeness

When finishing the defrosting process you must ensure that the defrosting is absolutely complete. Selecting the right defrosting temperature is an important requirement in this respect.

- If the defrosting temperature is set too low this impairs the unit's effectiveness from one defrosting to another with the removal of "ice-spots".
- If the defrosting temperature is set too high this causes extreme water vapour formation, which
 causes frost and ice to form around the unit.

Settlingtime

A period (approx. 5 to 8 minutes) between when the defrosting finishes and when the unit is activated has been proven to be necessary, as the unit's heat exchanger can drip off completely and the defrosting water can flow away through the drip water tray drain during this period.

Delayedfanstart

If the fans' activation is delayed by a further period (approx. 3 to 5 minutes), then the defrosting heat from the heat exchanger is absorbed and it is not given off into the room as warm-moist air.

10.5.2 Defrostcontrol

- The defrosting process is started at pre-set intervals or as required.
- The process completion must be ensured twice (time/temperature and temperature/temperature).
- For defrost operation (circulation air, electric, hot gas (optional)) the correct on-site installation of the defrosting sensor must be ensured. See defrosting procedure listed below.
- · Recommendation perform the defrosting process at the following times:

Electricdefrosting

Coldoperation	Х					
Suctionoperation		X				
Defrostoperation			X			
Dripphase				X		
Freeze onphase					X	
Coldoperation						X
Fans	Operation	Operation	Off	Off	Off	Operation

The duration of the individual phases depends from a variety of factors (e.g. temperature, moisture, etc.) in the particular application.

Hot gas defrosting(option)

Coldoperation	X				
Suctionoperation		X			
Defrostoperation			X		



Dripphase				X		
Freeze onphase					X	
Coldoperation						X
Fans	Operation	Operation	Off	Off	Off	Operation

The duration of the individual phases depends from a variety of factors (e.g. temperature, moisture, etc.) in the particular application.

10.5.3 Circulation air defrosting

With operation of the units at room temperatures in the plus range (plus-cold storage rooms) and evaporation temperatures $t_0 = 0$ to -5°C, circulation air defrosting is usually sufficient: with shut-off working fluid-carrying lines the required defrosting heat is generated by the fan heat flow and the air temperature in the plus range. But it also applies here: the refrigerating operation may be restarted, as described, only after complete defrosting.

10.5.4 Electric defrosting

The following must be ensured here: With alternating defrosting within a room (group defrosting), use defrost closure devices (defrost flaps, textile closure devices)! An on-site monitoring with a safety device (temperature limiter; to be planned for in creating the annex) must be provided in acc. with EN 60519-2; VDE 0721; T. 411 to rule out the danger of the units overheating. Operation without a temperature monitor is forbidden! The max. permissible fuse for the electric heating groups with 20 A must be complied with without fail. The min. fusing is provided in the order-related connection diagrams. To prevent the permissible pressure in the unit from being exceeded with electric defrosting systems, in acc. with EN 378-2 either working fluid displacement must be enabled or a suction circuit must be provided.

A separate control of the coil and tray defrosting is possible (see note in electric connection plan). With average usage conditions a reduced defrosting capacity in the coil can be adjusted with a simple wiring change (see separate electric connection plan).

10.5.5 Hot gas defrosting(option)

With defrosting with hot gas it must be ensured that at the point of defrosting enough other consumers are in the cold operation so that a big enough hot gas volume is available (approx. 2-3 times the defrosting power compared with the cooling capacity can be expected as reference value).

10.5.6 Further notes on defrosting

The drains of the drip trays must be heated (apart from plus-cold storage rooms), so that ice formation is preventedhere.



11 Plans/diagrams

11.1 Electrics documentation

11.1.1 Fan motor connectiondiagram

See motor terminal box cover inside on the fan.

11.1.2 Connection diagram electrical defrost

See order-related offer documents

